

Gorilla Cage Installation Instructions

Installation of this Gorilla Cage should go quickly and easily with just a few simple steps as follows:

Note: In order to reduce your shipping costs you may have been shipped a unit with a two piece concrete form. If so, accurately lay out the two pieces in their respective positions and use the supplied splice plates to hammer the halves together. The splice plates are best installed with a hammer while backed up by a hard concrete surface. Test fit the cage on the form before proceeding.

1. Level the ground that the concrete form and cage will sit on.
2. Place the concrete form in position and confirm everything fits by temporarily setting the cage in position on top of the form using the provided PVC sticks.
3. Remove the cage and mix the cement.
4. Fill the cement form to the top edge of the form and work to a reasonable level. The securing eyebolts are factory set for spacing and height. Do not adjust unless needed. The eyebolt should be approximately 3/4 exposed above the cement level to allow the lock hasp to fit through.
5. You can set the cage over the eyebolt hardware while the cement is still wet by using the provided PVC sticks to transfer the weight to the form.
6. Install your locks into each end being sure to capture the exposed eyebolt to secure the cage. We recommend a lock with a 3/4" to 1" hasp.

If you have any questions with reference to installing this Gorilla Cage please contact us at (281) 705-9701.